

Notes de publication Sanako Lab 100 v10.40

Instructions d'installation

- Assurez-vous de posséder une licence pour le Lab 100 v10.00 avant d'exécuter le programme d'installation. Les clients couverts par la Maintenance Logicielle peuvent obtenir une licence auprès de leur distributeur local.
- Exécutez setup.exe avec des droits d'administration pour installer le logiciel Lab 100 v10.40

Notes d'installation

- Cette version inclut en interne le codec MP3 Lame, il n'est ainsi plus nécessaire d'installer un codec MP3 séparé
- Toutes les données concernant la configuration et les professeurs sont sauvegardées dans le dossier « C:\Documents And Settings\Shared Documents\SANAKO\Lab100\ » sous Windows XP ou « C:\Users\Public\Documents\SANAKO\Lab 100\ » sous Windows Vista et Windows 7. Assurez-vous de sauvegarder vos données régulièrement.
- Veuillez noter que certaines cartes réseau ne détectent pas automatiquement la vitesse de connexion, ce qui signifie que sélectionner une vitesse de transmission trop élevée peut provoquer des erreurs de communication entre le PC Professeur et le MSU. Dans ces cas, nous vous recommandons de forcer la vitesse de communication entre le PC Professeur et le MSU à 100 Mbps Semi-Duplex. Ceci peut être effectué dans le Gestionnaire de périphériques du PC Professeur.

Correctifs 10.30 vers 10.40

- Cette mise à jour corrige un problème où les UAPs élèves perdaient la capacité de lire l'audio après l'arrêt de l'ordinateur de l'enseignant.

Correctifs et modifications 10.20 vers 10.30

- Lab 100 Multimedia features available with separate token
- Fixed issue with multi MU installations and file management
- Fixed issue where Config application crashed when adding additional MU
- Fixed issue where Podcast button was available in the file collection dialog even when Podcasting was not enabled
- Fixed issue where the Podcast function did not work properly
- Fixed issue where AP Exam file naming did not match new requirements and added new code dialog to AP Exam
- Fixed issue where Dual Channel PSI disappeared from the audio sources
- Fixed issue where sidetone was disabled by default in the Listening Comprehension activity
- Fixed issue with printing classroom layouts
- Fixed issue where STUDENT_MEDIA_FILE was missing from the source types
- Fixed issue where creating a subfolder in MU caused Lab 100 to crash
- Fixed issue where replication did not work if changes had been made to subfolders
- Fixed issue where AOD file list was not saved properly if it included files from subfolders
- Fixed issue where the group number of collected files started from 0 instead of 1
- Fixed issue where extra files were collected in Pair and Group discussion when using random pairs
- Fixed issue where files were collected incorrectly when using manual pairing
- Fixed issue where the recording of the last group in Pair Discussion was not collected if it had fewer students than the other groups

- Fixed issue with 'Error 6' crash when collecting a single group recording
- Fixed issue where system crashed when creating a folder in MU in the Copy Files / File Collection window without clicking on the directory view
- Fixed issue where system crashed when creating a folder to the top of the left folder tree in the Copy Files / File Collection window
- Fixed issue where system crashed when creating a new folder when Desktop was selected in the Copy Files / File Collection window
- Fixed issue with 'WARNING 7000' error message

Correctifs et modifications 10.10 to 10.20

Correctifs

- Fixed issue where creating a subfolder in MSU caused an error and Lab 100 crashed
- Fixed issue where replication did not work if changes had been made to subfolders
- Fixed issue where the Audio on Demand file list was not saved properly if some of the selected files were in subfolders
- Fixed issue where the group numbers in Discussion activity collection started from 0 instead of 1
- Fixed issue where the Self Access activity did not work if some of the selected files were in subfolders
- Fixed issue where the information in collected files referenced the physical SCU collection port instead of UAP number
- Fixed issue where the Collect to USB button was active even if there was no USB in MSU USB port
- Fixed issue where if MSU was selected as the media source, opening a common dialog resulted in some flickering, especially if there was a Windows Explorer window open in the background
- Fixed issue where extra files were collected in Pair and Group Discussion when random pairs were used
- Fixed issue where files were collected incorrectly when manual pairing was used
- Fixed issue where the last group was not collected in Pair Discussion if the group was only partially full
- Fixed issue where the file copy and collection windows crashed when creating a folder in MSU without clicking the directory window, when selecting the top of the leftmost folder tree and creating a folder, or when creating a new folder when Desktop was selected

Problèmes connus

- Interpreter does not work in port 1
- Self-Access positions may occasionally become unresponsive
- Source settings in Config may occasionally become undone

Correctifs et modifications 10.00 to 10.10

Correctifs

- Fixed issue where student recording was not working properly and source material was not saved in Q&A activity
- Fixed issue where in Library mode couldn't use files from a subfolder
- Fixed issue where Quiz results were not shown correctly in student icons after the first question
- Fixed issue where Recovery Tool application was not working
- Fixed issue where copy to/from MSU window would not refresh folders/files correctly
- Fixed issue where copy to/from MSU window displayed an error message when clicking on anything other than folder or file names
- Fixed issue where MSU file replication collected 0 sized files
- Fixed issue where bookmarks were not shown in teacher's monitoring window
- Fixed issue when trying to recover files the error message "Fldrvw70.ocx missing" was displayed
- Fixed issue where German language was not available in Lab 100 v.10
- Fixed issue where doing a partial collect would never end and Lab 100 needed to be restarted
- Fixed issue where MSU watch2 was missing the "Shutdown MSU" option
- Fixed issue where volume control worked incorrectly in teacher monitoring window

Problèmes connus

- After student file collection the collection folder will not be opened for the teacher
- In STS activities 'Introduction' doesn't work correctly when there's over 50 UAPs

Correctifs et modifications 9.3 to 10.00

- Possibility to copy files in MP4 format to and from the MSU
- .NET Platform
- Improved student selection to sessions
- Arabic and Hebrew localizations have correct window form layout
- Fixed minor issues with Background Collect and improved collection speed
- Audio transcoding creates artifactless wav files to msu
- Screen resolution warning not displayed when large fonts are used
- Fixed issue where Background Collect did not allow wma conversion after collecting files in wav format
- Fixed issue where the default language selection made in Lab 100 Config did not remain in effect if user changed the language in Menu-Properties in Lab 100
- Fixed issue where a MSU watch2 error was displayed when a Tutor laptop was started
- Fixed issue where using the MSU as media source did not work
- Fixed issue where uninstalling Lab100 also uninstalled some dll files unnecessarily
- Fixed issue where licenses were not deactivated when Lab 100 was uninstalled
- Fixed issue where Lab 100 Config crashed when setting default settings if SERIALCOMM was missing
- Fixed issue where Lab 100 installation stopped the Study server application on computers where Sanako Study was also installed
- Fixed issue where setting the default language in Lab 100 Config stopped application execution
- Fixed issue where copying audio files from CD to MSU did not work
- Fixed issue where student track collection sometimes failed
- Fixed issue where Automonitor timeout could not be changed
- Fixed issue where Lab 100 stopped working when automonitoring an absent student
- Fixed issue where MSU Access was sometimes denied
- Fixed issue where no query was shown about leaving UAPs on when exiting Lab 100
- Fixed issue where Lab 100 crashed when started in Demo mode and user clicked on an empty class view
- Fixed issue where MSU needed to be restarted after using Self Access
- Fixed issue where the wrong UAP state was shown after Lab 100 was closed
- Fixed issue where recorder status was not shown correctly
- Fixed issue where Help menu could not be opened if build version selection was checked
- Fixed issue where incorrect MSU version information was shown in Lab 100 Config
- Fixed issue where starting a second instance in Lab 100 Config did not bring the first instance to the topmost window
- Fixed issue where Tokens for other Sanako software were shown in Lab 100 Config license information
- Fixed issues with the About window layout
- Fixed issue where Lab 100 Config crashed when selecting a student directly after removing one
- Fixed issue where the Lab 100 STS Delegate port number could not be set
- Fixed issue where the Lab 100 software token was not released after uninstallation and could not be activated again after installation
- Fixed issue where the Web Help and Knowledge Base values were missing in Lab 100 Properties
- Fixed issue where Lab 100 software token could not be registered
- Fixed issue where STS Interpreters or STS Delegates could not be added in Lab 100 Config
- Fixed issue where students could not be selected in Lab 100 Config by holding down the Ctrl button and then left-clicking
- Fixed issue where the client data in a Lab 100 license did not affect the amount of possible connected students

- Fixed issue where Lab 100 tokens could not be activated, cancelled or registered in the Sanako license management application
- Fixed issue where Activation Tool error was displayed when starting Lab 100 without a license
- Fixed issue where Study licenses could be used for Lab 100 when using the "Restore Licenses" function in the Sanako license management application - Fixed issue where students did not hear the teacher in the GEPT activity when playing a sample
- Fixed issue where correct Quiz answers were not shown in the report graph
- Fixed issue with missing dll files
- Fixed issue where Lab 100 did not start
- Fixed issue where Lab 100 Config crashed when adding workstations
- Fixed issue where an error was sometimes displayed when using MSU
- Fixed issue where Lab 100 Config crashed after selecting "Find Workstations"
- Fixed issue where Lab 100 software token was not accepted
- Fixed issue where Lab 100 Config crashed when removing students
- Fixed issue where old license information was displayed in the About window
- Fixed issue where Self access setup did not work when an MSU file was selected
- Fixed issue where the GEPT exam code dialog was not shown
- Fixed issue where automonitoring stopped after the first student
- Fixed issue where the Activity menu items were not localized correctly
- Fixed issue where the Copy files to MSU function did not work
- Fixed issue where the Close button in the Copy files to/from MSU window did not work when used for a second time
- Fixed issue where a license control notification was shown in the Folder view
- Fixed issue where 'MSU warning 2002' was displayed in Library mode
- Fixed issue where student names could not be edited
- Fixed issue where Lab 100 crashed when New Session was selected
- Fixed issue where the .NET version of Lab 100 config did not allow the student layout to be edited
- Fixed issue where the title bar in the Copy to/from MSU window was in the wrong place
- Fixed issue where the wrong CD track position was shown
- Fixed issue where a Lab 100 error was shown when a seating plan was selected after a session
- Fixed issue where the Copy files to / from to MSU dialog opened when opening a media file
- Fixed issue where a .NET Framework error appeared when saving the master track
- Fixed issue where MSU files were not available for the third session
- Fixed issue where attendance could not be edited when Student Login was turned off
- Fixed issue where a speaking student was not also indicated as listening during a call
- Fixed issue where interface included an extra nonfunctional button
- Fixed issue where recorder status was incorrectly displayed after recorder controls were used
- Fixed issue where the Seating Plan graph was missing
- Fixed issue where recorder controls did not show UAP status
- Fixed issue where Attendance and Seating Plan reports did not fit into their windows
- Fixed issue where the Audio Source drop-down menu was disabled in Lock mode
- Fixed issue where an 'Unhandled exception' appeared when Attendance Report was selected
- Fixed issue where .NET Framework error appeared when Automonitor changed from the last student to the first one
- Fixed issue where the AP Exam activity was left hanging if All Call was used
- Fixed issue where student window did not open correctly when left-clicking a student icon
- Fixed issue where "On the air" was not shown when right-clicking a student icon
- Fixed issue where Attendance and Recorder status buttons were enabled during All Call
- Fixed issue where an exception occurred when CD Player was selected as the audio source and the CD was removed during playback
- Fixed issue where selecting students with the lasso selector did not work properly
- Fixed issue where mouse clicks were sometimes missed
- Fixed issue where the Free and Replay functions would play both tracks overlapping each other in the Q&A activity
- Fixed issue where the Controls button did not work in the STS Interpreting activities

- Fixed issue where Interpreters were unable to select each other after the activity name was edited in the STS Interpreting activity
- Fixed issue where student UAPs could not be controlled from the teacher's interface
- Fixed issue where canceling the Media File source selection cleared the media file from the session
- Fixed issue where the 'LAB 100 - Waiting' window did not close in Demo mode
- Fixed issue where Teacher call was activated if the recorder control view was shown repeatedly
- Fixed issue where old log files were not deleted automatically
- Fixed issue where Student UAP remote control sometimes did not work
- Fixed issue where incorrect UAP status was indicated
- Fixed issue where poor audio quality could be observed with some WAV files
- Fixed issue where Lab 100 crashed when no MSU file was selected in the Listening Comprehension activity
- Fixed issue where SCU32 performance was slow
- Fixed issue where student icons displayed the wrong recording state
- Fixed issue where the language selection in Lab 100 Config did not work
- Fixed issue where Edit and Mix were disabled if only student track was selected to be recorded
- Fixed issue where Lab 100 ver. 9.10 crashed if a user other than the one who installed it ran it
- Fixed issue where Audio on Demand file numbering was not consistent in UAP, teacher interface and file list
- Fixed issue where recording did not work in Lab 100 systems with old UAPs if Free was selected after a Phone conversation activity
- Fixed issue where Convert Dll created poor conversions when transcoding from 44kHz to 32Khz
- Fixed issue where student UAP control was not disabled when monitoring a student
- Fixed issue where an AP Exam with a seating plan would collect names along with the AP number
- Fixed issue where the All Call button became active during AP Exam and when clicked the exam would cease to work
- Fixed issue where CD Audio was not set as the default audio source in AP Exam
- Fixed issue where collected pair discussion files only displayed the pair numbers in the file name
- Fixed issue where Audio on Demand collect failed if UAP played an empty track
- Fixed issue where the My Settings window had an incorrect window title
- Fixed issue where File collection did not overwrite old files
- Fixed issue where Teacher remote control did not stop playback
- Fixed issue where program audio was not saved to the MSU in Lab 100 in Traditional Chinese Windows 7 environments
- Fixed issue where deleted folders in the MSU were not removed from the list
- Fixed issue where Grouping did not always display the groups correctly in the Group discussion activity
- Fixed issue where pressing buttons while the 'Waiting' window was displayed could cause Lab 100 to crash
- Fixed issue where the Collect and Save dialog consumed all CPU power
- Fixed issue where some toolbar items were missing in Copy to/from MSU
- Fixed issue where the installation package could not find WMEncoder setup
- Fixed issue where the Phone conversation activity was left hanging on "Waiting" when starting the activity
- Fixed issue where the program source file was not recorded or saved entirely in the Q&A activity
- Fixed issue where collecting student recordings did not work properly
- Fixed issue where Lab 100 interface crashed when started in 64 bit Windows 7 environments - Fixed issue where Controls button did not work when teacher was selected as source
- Fixed issue where the interface did not close and was left hanging when clicking the 'X' icon after ending an activity
- Fixed issue where the Lab 100 v. 9.0 interface became slow when using seating plan and recorder status
- Fixed issue where Web help pointed to an incorrect URL
- Fixed issue where interface became slow after loading seating plan
- Fixed issue where text was partially missing in the Help menu
- Fixed issue where grouping did not work correctly in the Group discussion activity

- Fixed issue where a howling sound or echo could be heard when monitoring a group activity
- Fixed issue where the application did not close down properly when MSU file selection was canceled or a non-media file was selected as the source
- Fixed issue where there was a delay when starting an activity
- Fixed issue where CD Audio stopped after pausing in the AP Exam activity in Lab 100 v. 9.0
- Fixed issue where students did not receive any audio in the AP Exam activity if the audio was paused and the test was then resumed
- Fixed issue where it was not possible to manually pair an odd student in Lab 100 version 8.x
- Fixed issue where Chinese characters did not fit in the file transfer window
- Fixed issue where the connection between the MSU and Tutor PC went down after a few days of use
- Fixed issue where MSU shut down the audio routing when sysman connection was ended
- Fixed issue where Lab 100 did not respond correctly when a MSU file used as the media source was at the end and Play and Stop were selected
- Fixed issue where folder creation to MSU failed
- Fixed issue where 'Error 7000' appeared in Background collection
- ased updating for future version in MSU